











Assembly Instruction






Panel No	Panel Sizes	Quantity
1	1500*400*16	1
2	1500*400*16	1
3	268*399*16	1
4	268*399*16	1
5	268*399*16	1
6	268*362*16	1
7	268*379*16	1
8	350*100*16	1


Panel No	Panel Sizes	Quantity
9	264*368*16	1
10	352*375*16	1
11	278*735*5	1
12	278*735*5	1
13	350*80*12	1
14	350*80*12	1
15	304*80*12	1
16	348*314*5	1




Fittings



A=20




B=20




C=20



D=28



E=8




F=1




M6*16

G1=21




I3=2




J-1=4



H=1



J-2=2




L=4




O=8




P=8



N=1



J-3=1



U=2



M3.5*12

V1=8




Z1=21




Z2=21

1









1

2




B=20


2




3




4




5




6



7




8




9


9-1




9-2




9-3




10




11




12




13




14



15



卢克斯电视柜邮购包装图



Panel No		Panel Sizes	Quantity
17	护角	50*50*50	8
18	泡沫	1500*410*10	2
19	泡沫	450*100*40	2
20	泡沫	1500*100*20	2
21	泡沫	80*58*15	1
22	泡沫	400*21*15	1
23	泡沫	714*55*15	1
24	泡沫	100*29*15	1
25	泡沫	400*92*15	1
26	泡沫	642*32*15	1

Panel No		Panel Sizes	Quantity
27	泡沫	80*35*10	1
28	泡沫	735*42*10	1
29	泡沫	400*421*5	1
30	泡沫	314*52*5	1
31	泡沫	380*160*50	2
32	纸盒	内径1590*460*110	1